



SZABO SCANDIC

Part of Europa Biosite

Produktinformation



Forschungsprodukte & Biochemikalien



Zellkultur & Verbrauchsmaterial



Diagnostik & molekulare Diagnostik



Laborgeräte & Service

Weitere Information auf den folgenden Seiten!
See the following pages for more information!



Lieferung & Zahlungsart

siehe unsere [Liefer- und Versandbedingungen](#)

Zuschläge

- Mindermengenzuschlag
- Trockeneiszuschlag
- Gefahrgutzuschlag
- Expressversand

SZABO-SCANDIC HandelsgmbH

Quellenstraße 110, A-1100 Wien

T. +43(0)1 489 3961-0

F. +43(0)1 489 3961-7

mail@szabo-scandic.com

www.szabo-scandic.com

[linkedin.com/company/szaboscandic](https://www.linkedin.com/company/szaboscandic) 

Quick-RNA™ Midiprep Kit

RNA from any sample

Highlights

- Spin-column purification of RNA (up to 1 mg) from cells and tissue.
- High-quality RNA is ready for any downstream application.

Catalog Numbers:
R1056



Scan with your smart-phone camera to
view the online protocol/video.



Table of Contents

| | |
|-------------------------------------|-----------|
| Product Contents | 01 |
| Specifications | 02 |
| Product Description | 03 |
| Protocol | 04 |
| (I) Buffer Preparation | 04 |
| (II) Sample Preparation..... | 05 |
| Cells, Tissue | 05 |
| (III) Total RNA Purification | 06 |
| Ordering Information | 07 |
| Complete Your Workflow | 08 |
| Troubleshooting Guide | 09 |
| Notes | 10 |
| Guarantee | 13 |

Product Contents

| Quick-RNA™ Midiprep Kit | R1056 (25 prep) |
|--|----------------------------|
| ZR RNA Buffer | 100 ml |
| RNA Pre-Wash Buffer | 12 ml |
| RNA Wash Buffer ¹ (concentrate) | 6 ml |
| DNase/RNase-Free Water | 10 ml |
| Zymo-Spin™ V-E Columns w/ Reservoir | 25 |
| Collection Tubes | 50 |
| Instruction Manual | 1 |

Storage Temperature - Store all kit components (i.e., buffers, columns) at room temperature.
Before use:

1 Add 24 ml 100% ethanol (26 ml 95% ethanol) to the 6 ml **RNA Wash Buffer** concentrate.

Specifications

- **Sample Sources** – Cells (animal, gram(-) bacteria), soft and easy-to-lyse tissue, and enzymatic reactions (e.g., DNase I treated, Proteinase K treated). Not compatible with whole blood¹, urine¹, or samples in DNA/RNA Shield™².
- **Size** – Total RNA including small/microRNAs (≥ 17 nt).
- **Purity** – A_{260}/A_{280} & $A_{260}/A_{230} > 1.8$. RNA is ready for Next-Gen Sequencing, RT/qPCR, etc.
- **Binding Capacity** – Zymo-Spin™ V-E Column yield up to 1 mg RNA.
- **Elution Volume** – ≥ 200 µl DNase/RNase-Free Water.
- **Equipment Needed (user provided)** – Vacuum manifold, microcentrifuge, vortex.

¹ For RNA purification from whole-blood and urine, see the Quick-RNA Miniprep Plus Kit (R1057, R1058) or the Quick-RNA MagBead Kit (R2132, R2133).


² For RNA purification from samples in DNA/RNA Shield™, see the Quick-RNA Microprep kit (R1050, R1051), the Quick-RNA Miniprep Kit (R1054, R1055), the Quick-RNA Miniprep Plus Kit (R1057, R1058), the Quick-RNA MagBead Kit (R2132, R2133), or the Quick-RNA 96 Kit (R1052, R1053).

Product Description

The **Quick-RNA™ Midiprep Kit** provides a quick method for the isolation of high-quality RNA of up to 1 mg from cells (animal, buccal, buffy coat) and soft, easy-to-lyse tissue.

The procedure uses unique spin-column technology that results in high-quality RNA. Simply add the provided **ZR RNA Buffer** to the sample and bind RNA directly on the **Zymo-Spin™ V-E Column**. Then wash and elute. RNA is ready for Next-Gen Sequencing, RT/qPCR, hybridization, etc.

High-Quality RNA



RNA isolated with the **Quick-RNA™ Kits** is DNA-free. Samples isolated with Supplier Q's kit are provided for comparison. Total RNA was isolated from 10^6 human epithelial cells. Each amplification curve represents an average of three independent isolation experiments.

Protocol

The protocol consists of: (I) Buffer Preparation, (II) Sample Preparation and (III) Total RNA Purification.

(I) Buffer Preparation

- ✓ Add 24 ml 100% ethanol (26 ml 95% ethanol) to the 6 ml **RNA Wash Buffer** concentrate.

(II) Sample Preparation

- ✓ Perform all steps at room temperature and centrifugation at $\leq 500 \times g$ for 30 seconds, unless specified.

Cells

- To pellet cells:** Centrifuge liquid sample at $\leq 500 \times g$ for 1 minute and remove the supernatant. Then resuspend the cell pellet in **ZR RNA Buffer** (see table below).
- Adherent cells:** Remove liquid media from the culture container. Then add **ZR RNA Buffer** directly to the monolayer (see table below). Remove cells from the culture surface by scraping, pipetting, scraping, etc.
- Cells in suspension:** Add ≥ 3 volumes **ZR RNA Buffer** to 1 volume of liquid sample and mix well.

| Mammalian | Add ZR RNA Buffer ¹ |
|---------------|--------------------------------|
| $10^3 - 10^8$ | ≥ 6 ml |

To remove particulate debris, centrifuge and transfer the supernatant into a new nuclease-free tube (not provided). Then proceed to purification, page 6.

Tissue

≤ 100 mg low yield tissue (or ≤ 50 mg high yield tissue) can be mechanically homogenized in ≥ 6 ml **ZR RNA Buffer** with a mortar/pestle, dounce, syringe, tissue grinder, or bead beating (recommended). To remove particulate debris from homogenate, centrifuge and transfer the supernatant into a new nuclease-free tube (not provided). Proceed to purification, page 6.

Recommended: Use ZR BashingBead Lysis Tubes (#S6003; sold separately) and a high-speed homogenizer (e.g., MP Bio FastPrep-24, Bertin Precellys) for 30-60 seconds.

¹ If the sample lysate is turbid, the volume of **ZR RNA Buffer** can be increased for complete lysis of the sample (sample lysate should appear clear with no particulate debris).

(III) Total RNA Purification

- ✓ Perform all steps at room temperature and centrifugation at 10,000-16,000 x g for 30 seconds, unless specified.
- 1. Add 1 volume¹ ethanol (95-100%) to 1 volume sample lysed in **ZR RNA Buffer** (1:1) and mix well.

Example: Add 6 ml ethanol to 6 ml mixture (sample lysed in **ZR RNA Buffer**).
- 2. Transfer the mixture into a **Zymo-Spin™ V-E Column**² with reservoir mounted on a vacuum manifold and start vacuum³.
- 3. Remove the reservoir and transfer the column into a **Collection Tube**. Then centrifuge the column.
- 4. Add 400 µl **RNA Pre-Wash Buffer** to the column and centrifuge. Discard the flow-through.
- 5. Add 400 µl **RNA Wash Buffer** to the column and centrifuge. Discard the flow-through.
- 6. Add 400 µl **RNA Wash Buffer** and centrifuge the column for 2 minutes to ensure complete removal of the wash buffer. Then carefully, transfer the column into a nuclease-free tube (not provided).
- 7. Add ≥ 200 µl **DNase/RNase-Free Water** directly to the column matrix and centrifuge.

The eluted RNA⁴ can be used immediately or stored frozen.

1 For total RNA without small/micro RNAs (17-200 nt), proceed directly to step 2.

2 To process samples > 400 µl, columns may be reloaded.

3 Set vacuum source at ≥ 500 mm Hg.

4 Eluted RNA can be DNase I treated using DNase I Set (cat. #E1010). For the protocol, see the RNA Clean & Concentrator-100 (cat. #R1019).

Ordering Information

| Product Description | Catalog No. | Size |
|-------------------------|-------------|-----------|
| Quick-RNA™ Midiprep Kit | R1056 | 25 preps. |

| Individual Kit Components | Catalog No. | Amount |
|-------------------------------------|---------------------------|-----------------|
| ZR RNA Buffer | R1020-1-100 | 100 ml |
| RNA Pre-Wash Buffer | R1020-2-50 R1020-2-100 | 50 ml 100 ml |
| RNA Wash Buffer (concentrate) | R1003-3-6 R1003-3-12 | 6 ml 12 ml |
| Zymo-Spin™ V-E Columns w/ Reservoir | C1029-25 | 25 |
| Collection Tubes | C1001-50 | 50 |
| DNase/RNase-Free Water | W1001-6 W1001-10 | 6 ml 10 ml |

Complete Your Workflow

- ✓ For tough-to-lyse samples, use ZR BashingBead Lysis Tubes:

| ZR BashingBead Lysis Tubes | |
|----------------------------|----------------------------|
| 2.0 mm beads #S6003 | Plant/animal tissue |
| 0.1 + 0.5 mm beads #S6012 | Microbes |
| 0.1 + 2.0 mm beads #S6014 | Microbes in tissue/insects |

- ✓ For isolation of RNA from any sample:

| Quick-RNA kits | |
|----------------------------|---|
| Miniprep Plus #R1057/R1058 | $\leq 10^7$ cells, ≤ 50 mg tissue |
| MagBeads #R2132/R2133 | Automatable (Tecan, Hamilton, Kingfisher, etc.) |


- ✓ For clean-up (purification) and concentration of any RNA sample. (e.g., from the aqueous phase of TRIzol[®] extractions) or from any enzymatic reaction (e.g., DNase I treated RNA):

| RNA Clean & Concentrator kits | |
|-------------------------------|---|
| Microprep #R1013-R1014 | DNase I Set included |
| MagBeads #R1082 | Automatable (Tecan, Hamilton, Kingfisher, etc.) |

- ✓ For NGS:

| Zymo-Seq RiboFree Total RNA Library Prep kit | |
|--|----------|
| #R3000 | 12 preps |
| #R3003 | 96 preps |

Troubleshooting Guide

| Problem | Possible Causes and Suggested Solutions |
|---|---|
| <p>Precipitation, viscous lysate</p> | <p>Incomplete lysis and/or high-mass input:</p> <ul style="list-style-type: none"> - If precipitation occurs (upon adding ethanol to the lysate) or if the lysate is extremely viscous, increase the volume of ZR RNA Buffer to ensure complete lysis and homogenization until lysate is transparent (see image).  |
| <p>Low purity (A_{260}/A_{230} nm, A_{260}/A_{280} nm)</p> | <p>Sample handling:</p> <ul style="list-style-type: none"> - Ethanol and/or salt contamination. After centrifugation steps, carefully remove the column from the collection tube to prevent buffer carryover. Alternatively, blot emptied collection tube with a tissue or towel. - Make sure lysate and wash buffers have passed completely through the matrix of the column. This may require centrifuging at a higher speed and/or longer time. <p>Incomplete lysis and/or cellular debris:</p> <ul style="list-style-type: none"> - Increase the volume ZR RNA Buffer (proportionally) to ensure complete lysis and homogenization. Be sure to centrifuge any cellular debris and then process the cleared lysate. |
| <p>Low yield</p> | <p>Sample input:</p> <ul style="list-style-type: none"> - Too much input or incomplete lysis/homogenization can cause cellular debris to clog or overload the column and result in compromised nucleic acid recovery. Use less input material and/or increase the volume ZR RNA Buffer |
| <p>DNA contamination</p> | <p>To remove DNA:</p> <ul style="list-style-type: none"> - Perform DNase I treatment post-purification, then re-purify the treated sample. See DNase I Set #E1010 and the RNA Clean & Concentrator kit #R1019. |

For technical assistance, please contact 1-888-882-9682 or email tech@zymoresearch.com

Notes



100% satisfaction guarantee on all Zymo Research products, or your money back.

Zymo Research is committed to simplifying your research with quality products and services. If you are dissatisfied with this product for any reason, please call 1(888) 882-9682.

Integrity of kit components is guaranteed for up to one year from date of purchase. Reagents are routinely tested on a lot-to-lot basis to ensure they provide the highest performance and reliability.

This product is for research use only and should only be used by trained professionals. It is not for use in diagnostic procedures. Some reagents included with this kit are irritants. Wear protective gloves and eye protection. Follow the safety guidelines and rules enacted by your research institution or facility.

TM Trademarks of Zymo Research Corporation
Quick-RNA[®] is a registered trademark of Zymo Research Corporation. Other trademarks: TRI Reagent[®], TRIzol[®] (Molecular Research Center, Inc.), RNAProtect[®], Allprotect[®], PAXgene[®] (Qiagen), RNAlater[®] (Ambion, Inc.), Universal (viral) transport medium (BD, Copan), Bioanalyzer (Agilent Technologies, Inc.).



ZYMO RESEARCH

The **BEAUTY** of **SCIENCE** is to Make Things **SIMPLE**®



tech@zymoresearch.com



www.zymoresearch.com



Toll Free: (888) 882-9682